PERFORMANCE DATA NO LOAD & NO DOOR OPENINGS AT 0° F FREEZER & 37° F FRESH FOOD (2500 ++ V5)					
Type A with Run/	65°F (18°C) Ambient		90°F (32°C) Ambient		
Start Capacitor	Variable Speed	Standard	Variable Speed	Standard	
Operating Time	74 to 84%	32 to 40%	100%	55 to 65%	
Freezer Temperature	-2° to 2° F -19° to -17° C	0° to 4° F -18° to -16° C	-1° to 3° F -18° to -16° C	-1° to 3° F -18° to -16° C	
Refrigerator Temperature	34° to 39° F 1° to 4° C	34° to 39° F 1° to 4° C	34° to 39° F 1° to 4° C	34° to 39° F 1° to 4° C	
Low Side Pressure (cut-in)	5 to 12 psig 43 to 83 kPa	5 to 12 psig 43 to 83 kPa	N/A	5 to 12 psig 43 to 83 kPa	
Low Side Pressure (cut-out)	-2 to 2 psig -14 to 14 kPa	-2 to 2 psig -14 to 14 kPa	-2 to 2 psig -14 to 14 kPa	-2 to 2 psig -14 to 14 kPa	
High Side Pressure (last 1/3 cycle)	90 to 105 psig 621 to 724 kPa	90 to 115 psig 621 to 793 kPa	120 to 135 psig 827 to 931 kPa	130 to 155 psig 896 to 1069 kPa	
Wattage (last 1/3 cycle)	50 to 60	90 to 130	60 to 70	100 to 140	
Amps (running)	0.5 to 0.9	0.7 to 1.1	0.6 to 1.0	0.8 to 1.2	
Base Voltage	115 vac (127 vac max)				

DEFROST SPECIFICATIONS

Cabinet Size	Thermostat		Heater	
Cabillet Size	Cut-in	Cut-out	Watts	Ohms
23' CD, 26'	25° F (-4° C)	47° F (8° C)	450	30

Electronic Timer - (ADC) Defrost 24 minutes every 6-96 hours of compressor run time.

CONDENSER FAN MOTOR				
Watts	RPM	Amps		
3.1	1100 CW Opposite Shaft	0.03 Running		


SERVICE DATA SHEET


A01461101

SIDE BY SIDE - R134a

IMPORTANT: PLEASE RETURN THIS SHEET TO ITS ORIGINAL LOCATION

			,			
ERROR CODES		SPECIAL MODES				
Disp	Display			Display		Activate/Deactivate
FZ	FF	Interpretation	Mode	FZ	FF	(press for up to 10 sec. simultaneously)
	OP-	Open FF mid-level thermistor	Manual Defrost	d	F	+ and -/same to deactivate
	OPT	Open FF upper-level thermistor	Display/ Showroom	77	77	^ and -/set
OP		Open FZ thermistor	Sabbath	Sb	Sb	V and +/same to deactivate
	SH-	Shorted FF mid-level thermistor	Diagnostic	No FF or all UI LED	FZ display, s on.	^ and V /+ to deactivate
	SHT	Shorted FF upper-level thermistor	Notes: • Always ch	neck for pir	n back-out	s, pinched or damaged wires before
SH		Shorted FZ thermistor	replacing components.			
SY	CF	Ul to Main Control Board communication failure; on start up	 Determine whether failure is caused by the component, main control board or wiring. Contact TID before replacing main control board. Refer to Service Manual for additional information. 			
SY	CE	Ul Main Control Board communication error; after a period in operation				
SY	EF	Evaporator fan failure				





DIAGNOSTIC MODE				
ctivate:	Press ^ and V temperature pads for up to 10 sec. simultaneously. Press + to advance through tests.			
eactivate:	Press + for up to 10 sec. Diagnostic Mode will automatically deactivate after 5 min. of inactivity. Note: Silence alarm.			

- Tests marked with "*" may not be applicable to this unit and will not be displayed in Diagnostic Mode.
- Tests displayed in diagnostic mode but not described below are for internal purposes only; advance through.
- View UI display for "on," "off," "CL," "OP," "SH," "LO," "HI" or numerical results of tests.
- Listen for operating sounds; feel for heat or air flow as appropriate to determine results of tests.

	Test	To activate test:	Passing result	
	First Screen		All LED lights on UI illuminated	
	Second Screen		All segments on UI temperature displays illuminated	
	Third Screen		Blank UI display, no lights illuminated, no shadowing; "-" and "+" blinking on FF display side to show location.	
28	Dispenser Paddle	Press disp. paddle	"on" on UI when depressed; "off" when released	
1*	Standard Compressor and Condenser Fan	Press set	Compressor and Condenser Fan running when "on"; stopped when "off"	
2	Defrost Heater	Press set	Defrost limit switch must be closed; verify "CL" in test 26. Feel for heat from defrost heater when "on". If "OP" in test 26, heater will not activate.	
3	FF Light	Press set	With FF door open, FF lights on when "on"; off when "off"	
8	Water Valve (Dispenser)	Press set	Be prepared to collect water at dispenser. Water dispenses when "on"; stops when "off"	
9	FZ Light	Press set	With FZ door open, FZ lights on when "on", off when "off"	
10	Auger Motor	Press set	FZ door must be closed. Motor running when "on"; motor stopped when "off"	
11	Cube/Crush Solenoid	Press set	Do not leave solenoid in activated state. Solenoid activated when "on"; deactivated when "off"	
41*	Perfect Temp Drawer (PTD)	Press set	PTD UI illuminated when "on", off when "off"	
12*	VCC Condenser Fan	Press set	Fan running when "on"; stopped when "off"	
38*	VCC Compressor	Press set	Compressor running when "on"; stopped when "off"	
15	Evaporator Fan	Press set	Fan running for minimum of 10 sec. when "LO" or "HI"; stopped when "off". Feedback failure if fan starts but runs less than 10 sec. Listen for speed change from "LO" to "HI".	
22	Damper	Press set	With inspection mirror, observe damper open when "OP"; closed when "CL"	
23	FF Door	Open/close FF door	"CL" on UI when door closed; "OP" when open	
24	FZ Door	Open/close FZ door	"CL" on UI when door closed; "OP" when open	
26	Defrost Limit Switch	Activates automatically	"CL" on UI when closed; "OP" when open	
36	Ice Chute Door	Depress ice chute door or press set	"OP" on UI when manually opened; "CL" when closed. Or, using "set", "OP" on UI when fully opened or "CL" when fully closed by the motor.	
29	FF Thermistor	Activates automatically	UI shows temperature sensed by FF thermistor; pass if within 10°F of temperature measured with gauge at mid-level FF thermistor location. "OP-" if open; "SH-" if short	
30	FZ Thermistor	Activates automatically	UI shows temperature sensed by FZ thermistor; pass if within 10°F of temperature measured with gage at FZ thermistor location. "OP" if open; "SH" if short	
33	Ambient Thermistor @ Main Board	Activates automatically	UI shows temperature sensed at main board; pass if within +20°F/-10°F of temperature measured with gauge at main board location. "OP" if open; "SH" if short	
34	Ambient Thermistor @ UI	Activates automatically	UI shows temperature sensed at UI; pass if within +20°F/-10°F of temperature measured with gauge at UI location. "OP" if open; "SH" if short	
46	Humidity Sensor	Activates automatically	"OP" if open, "SH" if short AC Heater System: Displays %RH DC Heater System: "HI" – heater should be on "Lo" – heater should be off %RH is displayed when humidity is between "Lo" and "HI" values; heater could be on or off.	
47*	Dispenser Pocket Heater	Press set	AC Heater System: ""; test not available DC Heater System: heater on when "on", off when "off"	
	1	I.B	Disales district	
0-	Firmware Parameters	Press set	Displays digit sequence; record	
0- 2-	Firmware Parameters Main Board Firmware	Press set Press set	Displays digit sequence; record Displays digit sequence; record	

IMPORTANT SAFETY NOTE

The information provided herein is designed to assist qualified repair personnel only. Untrained persons should not attempt to make repairs due to the possibility of electrical shock. Disconnect power cord before servicing this appliance.

IMPORTANT

If any green grounding wires are removed during servicing, they must be returned to their original position and properly secured.



All electrical parts and wiring must be shielded from torch flame. DO NOT allow torch to touch insulation; it will char at 200°F and flash ignite (burn) at 500°F. Excessive heat will distort the plastic liner.

